

View Timer

Get money from people for the time they use your computer by installing View Timer

ENCOURAGES PEOPLE TO SPEND MORE MONEY
VERY USER FRIENDLY

View Timer is a system which accepts ten cent up to two dollar coins in a coin box, controls the use of the Computer and displays the time remaining on the Computer screen right in front of the user.




Coin Box

Accepts 10 Cent up to \$2 Coins


Features:

- Time Remaining always in view on screen
- On screen warning messages at 2 and 1 minutes remaining which prompts users to put in more money
- Audible Alarm with all messages
- On Screen Instructions for users
- Accepts 10 20 50 \$1 \$2 coins
- Very easy to install
- Runs on Windows 95 / 98 / NT / 2K / XP
- Disables Keyboard and mouse when time expires
- Easily adjustable with security password for Cents per Minute and maximum number of coins required to start
- Automatically totals all the coins entered to enable auditing of coins collected
- Can be retro fitted to existing systems

Time Remaining
Floating window



Warning Window
2 minute Pop up



On Screen Instruction Window




Close Down Window

View Timer

Accessing the Setup Menu

1.

With your mouse, Left Click near the left edge of the green window or the Time Remaining window as shown by the X




2.

Type in your Access code. The default code is 1234. Then click the OK button.




3.

Select **Coms** to setup the PC communications with the coin box or select **Setup** to alter pricing etc.



Coms Window



4.

Select the Com Port Number that you are using.

Click the up or down arrows to set the minimum amount for the system to start.

The Coin Counter value shows the total amount of coins entered since you last cleared the value by clicking on the **Reset Counter** button.

The default password is 1234. You should enter a new password here but make sure you do not forget what it is otherwise you will not be able to access this Setup window again.

Checking this box will enable the Beeper sound in the Coin Box.

5.

Click the up or down arrows to set the price per minute.

Setup Window

